


Read very carefully!

This button size guide must be printed onto paper at a 1:1 scale for it to work. You may have to deselect "fit-to-page" or "shrink-to-page".


The whole point is that the scale will not work on a computer / tablet / phone screen as the button sizes will appear larger or smaller depending on what your computer does to make the image fit onto your screen.

So, print out this PDF and then check for calibration by placing a 2p or 1p coin over the corresponding image and measuring against the 10cm scale to ensure accuracy.



Button sizes are always in lignes - pronounced "lines" - e.g. 32^{'''} or 32L is 32 lignes. 40^{'''} = 1" = 25.4mm. Use the scale diagram below to choose your button size.

Be aware that differing fabric thicknesses means that this can never be an entirely precise measurement!



When placing your order for buttons **be very careful to use the correct units.** Our default position is that you mean lignes, unless it is explicitly clear that you don't!